

ANTIQUUE TALL KITCHEN CLOCK

SOLUTION "A"

- 1) Starting at the hour, advance your minute hand **1 full hour**. Let it strike the hour.
- 2) Now, advance the minute hand to the half-hour and let it strike. Your clock should be striking once for the half-hour and several times for the hour. It may not be striking the correct number of times at the hour, if not, proceed to SOLUTION "B"

SOLUTION "B"

- 1) Move the minute hand to the hour and count the number of times that it strikes. Than move the hour (short) hand **only** so that it is pointing to the number that the clock just struck. The HOUR hand may be moved either forward or backwards.

Example

The clock struck 5 times and the hands show 7:00, move the hour hand backwards 2 hours. Now your hands show 5:00 corresponding to the 5 times your clock just struck.

Now reset the time according to the "SETTING TIME" procedure.

TIME ADJUSTMENT

The nut or knob on the bottom of the pendulum adjusts the time.

- 1) Gently hold-the pendulum to stop it from swinging then turn the round nut at the bottom of the pendulum
..... to the right to speed it up
..... to the left to slow it down.
(Do not turn it very much, about 1/4 turn each time)
- 2) Release the pendulum and give it a light push to start it swinging.
- 3) Reset the hands to the correct time.

*****DO NOT ADJUST MORE THAN TWICE PER DAY*****

SUGGESTIONS

- 1) Be sure the pendulum bob is resting on the regulating nut.
- 2) When moving/transporting the clock, take off the pendulum.
- 3) Stop the pendulum when you go on vacations. Try got to let the clock run down. Start and reset the clock when you come home.

SETTING THE ALARM

Not all tall kitchen clocks have the alarm mechanism.

- 1) Turn the small ring (located in the center of the dial, under the hands) so that the hour that you want the alarm to sound in under the hour hand.
example: If you want the alarm to go off at 7:00 turn the small dial so that the roman numeral VII is positioned under the hour hand
- 2) Wind the alarm mechanism only 3-4 times. If you wind it tight, it will sound for 10-15 minutes.
- 3) The only way to shut off the alarm is to let it run completely down by itself

“WE ALWAYS HAVE TIME FOR YOU”